

WORLD HEADQUARTERS 3879 North Richards Street ■ Milwaukee, WI 53212

TOLL-FREE 800-932-0685 ■ PHONE 414-964-3668 ■ FAX 414-964-5767

E-MAIL orders@fatsac.com or orders@barefootinternational.com ■ WEB www.barefootinternational.com

TYPE OF BOOM

- 1 B200 — DELUXE STRAIGHT BOOM**
Windshield is in front of pylon and pylon is **NOT** tapered.
- 2 B201 — DELUXE SINGLE / STRAIGHT CONTOUR BOOM**
Windshield is in front of pylon and pylon is tapered.
- 3 202 — DELUXE UNIVERSAL CONTOUR BOOM**
Windshield is even or up to 8 inches behind pylon.
- 4 B204 — DELUXE QUAD CONTOUR BOOM**
Windshield is more than 8 inches behind pylon.
- 5 B204-V — DELUXE QUAD V-DRIVE BOOM**
V-Drive boats with rear pylons. Make sure that the pylon is **STRAIGHT** at least 3 inches at the base where the clamp is attached or call the boat factory to get a replacement pylon that has at least 3 inches that is **STRAIGHT** at the bottom for Boom clamps to hold safely.
- 6 B205 — GUNNEL BOOM**
For boats **WITHOUT** factory installed pylons.
- 7 B202-XTI — MALIBU XTI BOOM**
This is for the new Malibu XTI with retractable pylons.

WARNING:

With all booms, the boom clamps must be attached below the taper on the pylon.