

# SLINGSHOT FOIL BOARD

SLINGSHOT

## PARTS:

1. SLINGSHOT FOIL BOARD
2. HARDWARE:
  - (4) BRASS T-NUTS
  - (4) M8 STAINLESS STEEL SCREWS

## FOIL Installation Instructions for Slingshot Boards

1. Place the board on the ground with the bottom facing up.
2. Unscrew M8 screws from T-nuts.
3. Place the T-nuts on far edges of tracks.
4. Place strut in desired position. Slide the T-nuts so that they line up with the holes in the base of the strut. Use a screw driver to move the T-nuts.
4. Tighten screws 3 - 5 turns to be able to readjust foil position in track. Find desired position and tighten screws fully.

